






<div style="text-align: right;"> ↑ Revision DATE: 3/17/04 REVISION: None, New CO Standard </div>		<h1 style="margin: 0;">FIBER OPTIC CABLE INSTALLATION</h1>	<h1 style="margin: 0;">CO</h1>
<div style="display: flex; justify-content: space-around; align-items: flex-end;"> <div style="text-align: center;">  <p>FIBER OPTIC SUPPORT CLAMP WITH CABLE INSERTS (2-1414)</p> <p>POLE INSTALLATION</p> </div> <div style="text-align: center;">  <p>ADSS FIBER CABLE</p> <p>CROSS ARM INSTALLATION</p> </div> </div>			
<div style="display: flex; justify-content: space-around; align-items: flex-end;"> <div style="text-align: center;">  <p>DOWNLEAD CUSHION (2-1403) 5/8" x 4" LAG BOLT W/WASHER & NUT DUCT SEAL TOP OF CONDUIT 2" CONDUIT STRAP 2" CONDUIT SCHEDULE 80</p> <p>WOOD POLE DEADEND</p> </div> <div style="text-align: center;">  <p>(2-3115) (2-2347) 1 1/4" POLE BAND (2-3105) DOWNLEAD CUSHION 5/8" MACHINE BOLT W/WASHER & NUT DUCT SEAL TOP OF CONDUIT 2" CONDUIT SCHEDULE 80 CONDUIT STRAP 1 1/4" POLE BAND</p> <p>STEEL POLE DEADEND</p> </div> </div>			
<p>Notes:</p> <ol style="list-style-type: none"> 1. Cable inserts need to be selected for the size of fiber optic cable. The same clamp can be used with different cable inserts. 2. For the TYPICAL installation on a wood pole, hardware can be thru-bolted or lagged to pole. 			

APPROVAL: Dave Redding DATE: 3/19/04